



SUP MANUAL

Congratulations on your purchase of a Z PRO Inflatable. Z PRO inflatable products are known around the world for their durability. You will be glad you chose Z PRO, not only because of the value, but also because of our products' excellent performance.

Please take the time to read through this handbook and familiarize yourself with the features of your new inflatable, and the techniques for proper care and maintenance that will assure you the years of service for which your Z PRO was designed.

Once again, thank you for choosing a Z PRO Inflatable!

CAUTIONS

1. **WARNING!** Because of the United States legal system, we are required to warn you that use of this product can result in injury or death. Use of this product is at your own risk, and only after reading and understanding all information contained in this manual. Use of this product is not recommended for individuals that have not been instructed in its proper use.

CAUTIONS Regarding your Inflatable

1. NEVER OVER-INFLATE your inflatable. (See section on Inflation.) DO NOT allow your inflatable to stand in direct sunlight when out of the water as this can cause expansion to the point of seam or fabric damage or bursting. Partially deflate to allow for heat expansion if your inflatable is to be left out of the water for more than just a few minutes.
2. Tighten your air valves snugly before you use your inflatable for the first time. Folding, packing, and transporting can easily loosen the valves. A valve tool is provided in your repair kit.

3. Check your valves regularly, and tighten as needed.

WARRANTY

All Z PRO Inflatables sold to the original consumer are warranted by Z Pro Inflatables, through Woosung I. B. Co., Ltd., to be free of defects in material and workmanship for a period of one year from the date of purchase under normal use and service. The warranty applies with the following stipulations:

1. The obligation of Z Pro Inflatables under this warranty shall be limited to the repair or replacement, at our option, of any inflatable or parts thereof which shall be demonstrated to be defective under the terms of this warranty. Z Pro Inflatables and/or any authorized dealer designated by us, shall be the final judge as to the extent of our responsibility under the warranty, if any. Any such replacement or repair shall be performed at our repair shop, authorized repair station or another location specified by us.
2. This warranty is void if the board is altered structurally or subjected to stress beyond the limits of the material and accessories.
3. This warranty does not expressly cover shipping to the authorized repair shop or return shipping to you.
4. This warranty does not cover any liability for any injury caused by the use of this product.
5. Contact information for warranty repair:

Tel: 864-836-2822

Z Pro Inflatables

232 Banks Road

Travelers Rest, SC 29690

CARE & MAINTENANCE

INFLATION

PLEASE READ BEFORE INFLATING YOUR BOARD!

Following are general instructions for inflation.

1. Unroll the board on a flat surface.
2. Make sure hand pump and inflation hose are firmly connected.
3. Remove the cap on the top of the valve.
4. Twist the inflation valve in the board to the open (down) position.
5. Insert pump hose and twist to lock into position.
6. Pump air into the board until reaching the recommended 15 to 18 psi.
7. Twist to remove the pump hose. This action should automatically lock the valve into the closed (up) position.
8. Fasten cover to protect inflation valve.
9. DO NOT use high pressure air pumps due to the danger of over-inflation.
10. Remember, heat from direct sunlight will rapidly increase the PSI of your board. This can happen in only minutes, and can cause structural damage. A good rule to follow: when your board is inflated, always keep it in the water. Never leave it out of the water in the hot sun (on the ground, rocks, sand, or on a trailer) unless you deflate your board to about one-half pressure, as the heat of the sun increases the pressure very rapidly.

FIN INSTALLATION

1. Insert fin into the base slot.
2. Slide fin all the way to the back of the slot.
3. Tighten fin into position with the provided screw.

FOLDING & TRANSPORTING

After opening the inflation valve, start rolling up the board from the front of the board, rolling towards the inflation valve in the rear. Rolling toward the valve will help to get additional air out. Continue rolling forward as compactly

as possible. Secure with a strap for easy transportation. Be sure to protect your board from rubbing against hard or sharp objects during transportation by wrapping in plastic or canvas as friction can wear a hole through the material.

REPAIRS

MAKING TEMPORARY REPAIRS

1. Included with each new Z PRO product is a repair kit containing a tube of one-part glue, a small piece of fabric, and a valve tool.
2. This glue is ONLY for temporary patches such as an emergency repair of an air leak due to a puncture of the air chamber.
3. Use the following steps for temporary repairs:
 - a. Cut a patch from the fabric (in your repair kit) about one inch larger than the hole.
 - b. Clean the patch and the area to be patched with MEK (methyl ethyl ketone).
 - c. Apply a thin layer of glue from your repair kit on the area to be patched on the board and on one side of the patch. (Make sure not to put glue beyond the area to be covered with the patch.)
 - d. Let the glue dry about 15 minutes or until no longer tacky. Then apply a second coat of glue to both the patch and the area on the board to be repaired. This time, just wait until the glue is almost dry, but still a little tacky. Place patch on damaged area. Press out all air bubbles and roll patch firmly.
 - e. Let dry for 20 minutes before continuing use.
 - f. Remember, this is only a temporary repair. Your board may need to be re-patched by a qualified repair person.

Z PRO INFLATABLES
A Division of Woosung CNA, LLC
232 Banks Road
Travelers Rest, SC 29690

864-836-2822

